

PERMIT REQUIREMENTS WATERPROOFING/FRENCH DRAIN

Permits are required for French drains, waterproofing foundation walls and sump pits. A completed Building Permit application must be submitted along with a survey plan of the property showing the proposed location of work. Permit fee is \$25.00 and can be paid at the time the permit is submitted or when it is picked up.

Prior to application being submitted the survey must first be taken to the McCandless Township Sanitary Authority at 418 Arcadia Drive to have them stamp the survey for verification that there are no easements where the French drain/waterproofing foundation walls/sump pits will be located.

If the builder has paid employees a Certificate of Insurance must be submitted from his insurance carrier verifying his coverage for workers' compensation. The builder's insurance carrier and policy number as well as Federal/State I.D. No. is also required for the application.

Following review by both the Zoning Officer and Building Inspector the Building Permit will be issued and the applicant notified by telephone.