

Smoke Alarms at Home

SMOKE ALARMS ARE A KEY PART of a home fire escape plan. When there is a fire, smoke spreads fast. Working smoke alarms give you early warning so you can get outside quickly.

SAFETY TIPS

- » Install smoke alarms inside each bedroom and outside each sleeping area. Install alarms on every level of the home including the basement.
- » Large homes may need extra smoke alarms.
- » It is best to use interconnected smoke alarms. When one smoke alarm sounds they all sound.
- » Test all smoke alarms at least once a month. Press the test button to be sure the alarm is working.
- » There are two kinds of alarms. Ionization smoke alarms are quicker to warn about flaming fires. Photoelectric alarms are quicker to warn about smoldering fires. It is best to use both types of alarms in the home.
- » A smoke alarm should be installed on the ceiling or high on a wall. Keep smoke alarms away from your kitchen and bathrooms to reduce false alarms.
- » Change the batteries to your smoke alarms at least once a year.
- » Replace all smoke alarms when they are 10 years old.



FACTS

- ❗ Smoke alarms should be installed inside every bedroom, outside each sleeping area, and on every level. Smoke alarms should be connected so when one sounds, they all sound. Most homes do not have this level of protection.
- ❗ Roughly 2 out of 3 fire deaths happen in homes with no smoke alarms or the alarms were not working.



Town of McCandless Fire Marshal
9955 Grubbs Rd. Wexford, PA 15090
www.townofmccandless.org